Practical No.4

AIM: - Write a program to implement the echo client.

SOFTWARE REQUIRED:- Operating System: - Ubuntu Python 3

THEORY:-

A **TCP Echo Client** is a network client that sends a message to a server and waits for the same message to be returned. Similarly, a **TCP Echo Server** is a network server that listens for incoming client connections, reads messages from clients, and sends back the exact message that was received (i.e., echoes the message). The communication happens over the **TCP (Transmission Control Protocol)**, which ensures reliable data transmission.


TCP Echo Client-Server Architecture:

TCP Echo Server:

- 1. **Create Socket**: The server creates a TCP socket to listen for client connections.
- 2. **Bind to Address**: The server binds the socket to an IP address and port number.
- 3. **Listen for Clients**: The server listens for incoming client connections.
- 4. **Accept Connection**: The server accepts the connection when a client requests it.
- 5. **Receive Message**: The server receives a message from the connected client.
- 6. **Echo Message**: The server sends the exact message back to the client.
- 7. **Close Connection**: The server closes the connection with the client and continues to listen for new connections.

TCP Echo Client:

- 1. Create Socket: The client creates a TCP socket to establish communication.
- 2. **Connect to Server**: The client connects to the server using the server's IP address and port.
- 3. **Send Message**: The client sends a message to the server (e.g., "Hello, Server!").
- 4. **Receive Echo**: The client waits for the server to send the same message back.
- 5. **Close Connection**: The client closes the connection once the echoed message is received



ALGORITHM

Server

- 1. Create a server socket and bind it to port.
- 2. Listen for new connection and when a connection arrives, accept it.
- 3. Read the data from client.
- 4. Echo the data back to the client.
- 5. Repeat steps 4-5 until "bye" or "null" is read.
- 6. Close all streams.
- 7. Close the server socket.
- 8. Stop.

Client

- 1. Create a client socket and connect it to the server"s port number.
- 2. Get input from user.
- 3. If equal to bye or null, then go to step 7.
- 4. Send user data to the server.
- 5. Display the data echoed by the server.
- 6. Repeat steps 2-4.
- 7. Close the input and output streams.
- 8. Close the client socket.
- 9. Stop.

CONCLUSION: -

Thus the program for TCP echo client server was executed and the output was verified.

Course Teacher Ms. Prajakta Sawle